



4G GPS SOS TRACKER



MODEL# EV04

USER GUIDE

Visit: www.SecuLife.us

TABLE OF CONTENTS

| | | |
|---------|--|----|
| | CHAPTER 1 | 3 |
| | QUICK SETUP GUIDE | 4 |
| READ ME | GETTING STARTED..... | 5 |
| | CHAPTER 2..... | 10 |
| READ ME | MEET YOUR DEVICE | 11 |
| | WHAT DO THE LED LIGHTS MEAN?..... | 12 |
| | CHARGING YOUR DEVICE..... | 13 |
| | ACTIVATING AN SOS ALARM | 14 |
| | MAKING A PHONE CALL | 15 |
| | SILENT MODE BUTTON | 16 |
| | CHAPTER 3: | 17 |
| | MAP PAGE | 18 |
| | NOTIFICATIONS | 19 |
| | MY DEVICES | 20 |
| | DEVICE DETAILS..... | 21 |
| | CREATE A GEO FENCE | 22 |
| | LOCATION HISTORY | 23 |
| READ ME | SET CONTACT NUMBER | 24 |
| | ENABLING ALERT SWITCH | 25 |
| | SET SOS NUMBER..... | 26 |
| | ANSWER MODE | 27 |
| | PHONEBOOK..... | 28 |
| | QUESTIONS | 29 |
| | SAFETY INFORMATION/WARNING/CAUTION | 30 |

CHAPTER 1

AN OVERVIEW ON THE QUICK INITIAL SETUP GUIDE

KEEP YOUR LOVED ONES SECURE AND
INDEPENDENT BOTH AT HOME AND ON THE GO.



QUICK SETUP GUIDE

1

ACTIVATE YOUR SERVICE PLAN ONLINE
RECEIVE A NEW PHONE NUMBER FOR
YOUR EV04-SOS TRACKER

2

SWITCHING DEVICE ON AND OFF
WITH A SIMPLE PRESS OF A BUTTON

3

DOWNLOAD THE MOBILE APP
TO REMOTELY MONITOR YOUR LOVED
ONE. ANYTIME. ANYWHERE!

4

LOGIN TO THE MOBILE APP
USE THE USERNAME AND PASSWORD YOU
ENTERED DURING ACTIVATION, THEN
LOGIN TO OUR APP!

5

UPDATE MOBILE APP SETTINGS
SET THE CORRECT INFO OF THE DEVICE
WEARER AND THE APP USER

1

ACTIVATE YOUR SERVICE PLAN ONLINE

YOUR SECULIFE® EV04-SOS TRACKER COMES WITH A PREINSTALLED SIM CARD; THE SIM CARD NUMBER IS LOCATED ON THE BOX. ACTIVATE THE SERVICE PLAN ON YOUR SIM ONLINE AND RECEIVE A NEW PHONE NUMBER ASSOCIATED TO THE DEVICE



VISIT: WWW.ACTIVATE.SECULIFE.US


WE WILL REGISTER YOUR EMAIL ADDRESS AND LINK THE DEVICE TO OUR SECULIFE® MOBILE APP WHEN ACTIVATING YOUR DEVICE SIM CARD, SO YOU DON'T HAVE TO MANUALLY REGISTER TO THE APP. YOU'LL RECEIVE AN EMAIL CONFIRMATION WITH THE NEW NUMBER FOR YOUR RECORDS AND TO BE USED TO UPDATE YOUR MOBILE APP DEVICE INFO ON THE FOLLOWING STEPS.

2

SWITCHING DEVICE ON AND OFF


TO TURN THE DEVICE ON:

PRESS THE CALL BUTTON FOR **1 SECOND**,
ALL THE LED WILL FLASH RAPIDLY.
THE DEVICE CAN ALSO BE TURNED ON
AUTOMATICALLY BY CHARGING VIA
MAGNETIC USB CABLE OR PUT IT INTO
THE DOCKING STATION.



TO TURN THE DEVICE OFF:

PRESS AND HOLD THE SIDE BUTTON AND
SOS BUTTON TOGETHER FOR **3 SECONDS**
UNTIL THE LEDS TURN OFF.



IF THE EV04 TRACKING DEVICE DOESN'T TURN ON, IT LIKELY
NEEDS TO BE CHARGED. CHARGE IT FOR SEVERAL HOURS
AND THEN TRY AGAIN.

3

DOWNLOAD THE MOBILE APP

TO DOWNLOAD, SCAN THE QR CODE BELOW FROM YOUR
CELLPHONE:



SECU LIFE



Scan QR Code on
iOS Device



Scan QR Code on
Android Device



www.Seculife.us/ios



www.Seculife.us/android

OUR MOBILE APP IS ALSO AVAILABLE ON APPLE APP
STORE OR GOOGLE PLAY STORE. SEARCH "SECU LIFE" TO
FIND THE APP.

4

LOGIN TO THE MOBILE APP

A FAMILY MEMBER OR THE CAREGIVER CAN OPEN THE MOBILE APP AND LOGIN TO THEIR ACCOUNT WITH A USERNAME AND PASSWORD THAT WAS CREATED DURING THE SIM CARD ACTIVATION PROCESS ONLINE.

- ENTER YOUR EMAIL ADDRESS AS USERNAME.
- ENTER YOUR PASSWORD.

Sign In

Enter username →

Enter Password →

Biometric login provides a convenient method for authorizing access to your app. Instead of having to remember your username and password every time you open your app

→  [Use Biometrics to Sign-in](#)


By continuing, you agree to accept our Privacy Policy & Terms of Service.

5

UPDATE THE DEVICE INFO ON YOUR MOBILE APP

WHEN YOU FIRST ACTIVATE YOUR SOS TRACKER-EV04'S SIM CARD ONLINE, THE DEVICE WILL BE ADDED INTO YOUR MOBILE APP ACCOUNT AUTOMATICALLY. YOU CAN ACTIVATE MULTIPLE DEVICES ONLINE, MAKE SURE YOU USE THE SAME EMAIL ADDRESS OF YOUR MOBILE APP IN ORDER ADD THE DEVICE UNDER YOUR MOBILE APP LOGIN ACCOUNT.

1. **TAP ON YOUR DEVICE TO GO TO THE DEVICE DETAILS TO SET/UPDATE ITS SETTINGS.**
2. **SET MAIN CONTACT NUMBER:** THE PERSON'S (ADMIN'S) PHONE NUMBER, CARING FOR THE SENIOR, TO RECEIVE APP ALERTS.
3. **SET SOS NUMBER:** LIST OF PHONE NUMBERS TO RECEIVE NOTIFICATION ALERTS WHEN THE SOS BUTTON IS TRIGGERED.



**DETAILED INFO OF THESE STEPS CAN BE
FOUND IN CHAPTER 3 OF THIS MANUAL.**

CHAPTER 2

MEET YOUR SECULIFE® EV04 - SOS TRACKER

A GAME-CHANGING, PERSONAL SECURITY
MONITORING SYSTEM FOR THOSE WHO MATTER
MOST IN YOUR LIFE!



MEET YOUR EV04-SOS TRACKER

FRONT



WHAT DO THE LED LIGHTS MEAN?



Cellular signal indicator--Green

| | | |
|----------------|--|--|
| Green | Light shows a single flash rapidly every 3 seconds | Light shows a double flash rapidly every 3 seconds |
| Meaning | The device has a stable cellular signal | The device is registered to the cellular network |



Positioning indicator--Blue

| | | | |
|----------------|--|--|--|
| Blue | Light shows a single flash rapidly every 3 seconds | Light shows a double flash rapidly every 3 seconds | Light off |
| Meaning | The device has no latest location fix | The device has latest location fix | The device is not fixing the latest location |



Power indicator--Red / Solid

| | | |
|--------------|-------------------------------|--|
| Red | Light on (solid) | Light shows a double flash rapidly every 3 seconds |
| State | Device has been fully charged | BLE connected |



Power indicator--Red / Blinking

| | | |
|--------------|---------------------------------|----------------------------|
| Red | Light blinking quickly | Red off or blinking slowly |
| State | Battery power is lower than 20% | The device is charging |

CHARGE YOUR DEVICE

THERE ARE TWO WAYS TO CHARGE YOUR DEVICE:

A) CHARGING BASE:

- PLACE THE DEVICE ON THE CHARGING BASE.
- CONNECT THE USB CABLE FROM THE CHARGING BASE TO THE AC ADAPTER.

B) BY MAGNETIC USB CABLE:

CONNECT THE DEVICE TO THE DEVICE AS SHOW IN PICTURE



FIRST TIME CHARGE

WHEN USING THE DEVICE FOR THE FIRST TIME, PLEASE FULLY CHARGE THE BATTERY FOR AROUND 3-4 HOURS. IN THE MEANTIME, YOU CAN ACTIVATE THE SIM CARD THAT COMES WITH THE EV-04 TRACKING DEVICE IF YOU HAVEN'T DONE IT YET.

WHEN THE BATTERY LEVEL FALLS BELOW 20% IT WILL SEND A LOW BATTERY WARNING MESSAGE TO RECIPIENTS ON THE CONTACT LIST VIA TEXT MESSAGE OR IN-APP NOTIFICATION.

USE ONLY THE SECOLIFE® AUTHORIZED CHARGERS




AVOID LEAVING THE MAGNETIC CABLE PORT ON METAL SURFACES TO AVOID A SHORT CIRCUIT THAT MIGHT CAUSE DAMAGE OR FIRE.

ACTIVATING AN SOS ALARM

SOS WILL IMMEDIATELY CONTACT THE EMERGENCY CONTACT LIST AND SEND AN SMS ALERT AND IN-APP ALERT.

WHEN YOU NEED HELP, PRESS THE SOS BUTTON FOR 3-4 SECONDS UNTIL YOU HEAR A VOICE PROMPT, INDICATING AN SOS ALARM. THIS STARTS THE SEQUENCE OF SENDING A "HELP ME!" TEXT MESSAGE TO YOUR EMERGENCY CONTACT NUMBERS FOLLOWED BY THE OUTGOING CALLS.

- IF THE DEVICE FAILS TO CONNECT TO THE FIRST NUMBER, IT WILL CALL THE SECOND NUMBER AFTER DELAY OF 10 SECONDS. IN CASE THE SECOND NUMBER FAILS TO BE CONNECTED AS WELL, THE SYSTEM WILL CONNECT TO THE THIRD NUMBER ETC.
- BETWEEN EACH CALL, THERE WILL BE A 10-SECONDS DELAY, DURING WHICH TIME, THE USER CAN STOP THE CALL SEQUENCE OR PREVENT A POSSIBLE FALSE ALARM BY PRESSING THE SOS BUTTON.




PLEASE REMEMBER TO PROGRAM EMERGENCY CONTACT NUMBERS. IT IS NOT MANDATORY FOR ALL SOS NUMBERS TO BE SET, HOWEVER MINIMUM OF ONE MUST ALWAYS BE SET.

Call button

MAKING A PHONE CALL

TO MAKE A CALL, PRESS THE CALL BUTTON FOR 3 SECONDS AND YOU WILL HEAR A BEEP, AND THEN IT WILL DIAL THE SECOND NUMBER ON YOUR PHONE BOOK.

YOU MAY SET THE FIRST AND 2ND NUMBER ON YOUR PHONE-BOOK AS THE SAME NUMBER.



TO END THE CALL, PRESS THE SOS BUTTON.



SILENT MODE BUTTON

DOUBLE-CLICK THIS BUTTON TO TURN OFF VOICE WARNINGS; DOUBLE-CLICK ONCE MORE TO TURN VOICE WARNINGS ON.



- PUT DEVICE ON CHARGING BASE MORE THAN 30 SECONDS, AND THEY WILL BE PAIRED AUTOMATICALLY VIA BLUETOOTH



CHAPTER 3

MEET OUR MOBILE APP

A NEW, NEXT-LEVEL, AND EASY WAY TO PROTECT
AND CONNECT WITH YOUR LOVED ONE. ANYTIME,
ANYWHERE!



SECU LIFE


MAP PAGE

MOBILE APP HOME SCREEN WILL DISPLAY THE **MAP** AND THE DEVICE(S) LAST SEEN LOCATION ON THE MAP. MOBILE APP ALSO HAVE OTHER FUNCTIONS AVAILABLE (**ADD FENCES, NOTIFICATIONS, MY DEVICES**) ON THE FUNCTION BAR TO TRACK, LOCATE AND SETUP THE SOS TRACKERS AT YOUR CONVENIENT.

CLICK TO SEE
DEVICE NAME

YOU CAN CLICK ON THE DEVICE TO SEE THE DEVICE NAME, BATTERY LEVEL & TRACKING INTERVALS. THE NAME CAN BE CHANGED FROM MY DEVICES PAGE.

YOU CAN SEE ALL OF YOUR DEVICES ON YOUR MAP, IF YOU HAVE MORE THAN A DEVICE ADDED TO YOUR MOBILE APP,






NOTIFICATIONS

SEE ALL THE NOTIFICATION RECEIVED FROM YOUR DEVICE

SEE THE ALERT TYPE AND THE DEVICE NAME WITH THE DATE & TIME OF THE ALERT.

IF YOU HAVE MULTIPLE DEVICES ADDED TO YOUR MOBILE APP, YOU WILL SEE ALL THE NOTIFICATIONS FOR ALL OF YOUR DEVICES FROM THIS NOTIFICATION PAGE. TO SEE THE NOTIFICATIONS OF A SPECIFIC DEVICE ONLY, YOU CAN GO TO: **MY DEVICES >> SELECT A DEVICE >> NOTIFICATIONS BUTTON ON THAT PAGE.**

| Notifications | |
|--|------------------|
| Fence Notification | 11/09/2021 16:03 |
| Device Susan is out of fence DR's Fence | |
| Fence Notification | 11/09/2021 14:17 |
| Device Susan is back to fence DR's Fence | |
| Fence Notification | 11/08/2021 12:22 |
| Battery Low Alert from Susan | |
| Fence Notification | 11/04/2021 18:34 |
| Device Susan is back to fence Home | |
| Fence Notification | 11/04/2021 14:58 |
| SOS Alert from Susan | |
| Fence Notification | 11/04/2021 14:48 |
| SOS Alert from Susan | |
| Fence Notification | 11/03/2021 16:31 |
| Device Susan is out of fence Park Fence | |
| Fence Notification | 11/03/2021 16:03 |
| Device Susan is back to fence Park Fence | |
| Fence Notification | 11/02/2021 14:55 |
| Device Susan is out of fence Home | |



Settings

MY DEVICES

FROM YOUR MOBILE APP HOME SCREEN, TAP ON "MY DEVICES" TO SEE LIST OF DEVICES, IF YOU HAVE MULTIPLE DEVICES. CLICK ON THE DEVICE TO GO TO THE "DEVICE DETAILS".

Click on + to Add a new Device


From **My Devices** page you will see

- Device Name (The name can be changed from Device Details)
- Battery level
- Device SIM card and IMEI #
- Last seen date/time.


Click on a device to go to "**Device Details**" to setup and update the device information at anytime.

*Device status Types

- Online: This is when Device status indicates its online and connected to the App.
- Offline: This is when the device is switched off or ran out of battery or no network signal is detected.



Click "My Devices" to see your device list



Settings

DEVICE DETAILS


FROM YOUR MOBILE APP HOME SCREEN, TAP ON "MY DEVICES" THEN CLICK ON THE DESIRED DEVICE TO ACCESS AND TO GO TO ITS "DEVICE DETAILS". NOTIFICATIONS | HISTORY | SETTINGS WILL BE EXPLAINED ON THE FOLLOWING PAGES ON THIS CHAPTER

GEO FENCES:

SELECT THE DESIRED GEO-FENCE (SUCH AS HOME, SCHOOL, PARK... ETC.) TO RECEIVE ALERTS WHEN THE DEVICE ENTERS OR LEAVES THESE AREAS.

TRACKING INTERVAL:

SET UP LOCATION UPLOAD INTERVALS. THIS IS HOW OFTEN DO YOU WISH THE DEVICE TO REPORT THE LOCATION, WE SUGGEST TO SETUP TO 12 HOURS TO ENHANCE BATTERY-SAVING MODE; THIS WILL ENSURE THE DEVICE HAS SUFFICIENT BATTERY POWER FOR ANY POTENTIAL SOS ALERTS.



GEO-FENCE

GEO FENCING, ALSO KNOWN AS "SAFE ZONES," CAN BE SET UP FROM THE MOBILE APP; YOU CAN ADD, EDIT OR REMOVE A GEO-FENCE AREA. ONCE A GEO FENCE IS CREATED YOU CAN SELECT THE FENCE(S), FROM DEVICE DETAILS PAGE, TO RECEIVE ALERTS WHEN ENTERING OR EXITING A GEO-FENCE AREA.

ADD GEO FENCE:

- CLICK ON **NEW FENCE** BUTTON FIRST THEN SET A PERIMETER ON THE MAP
- CLICK ON **SAVE** BUTTON AND ENTER THE FENCE NAME (SUCH AS HOME, DOCTOR'S OFFICE, PARK... ETC.).


RECOMMENDED GPS RADIUS OF 1000 FEET OR HIGHER TO REDUCE FALSE ALERTS.

YOU CAN SETUP MULTIPLE GEO FENCE LOCATIONS AS NEEDED.

DELETE GEO FENCE:

- TO DELETE A GEO FENCE, CLICK ON THE DESIRED FENCE FIRST, THEN CLICK ON **DELETE** BUTTON


CLICK TO ADD OR DELETE FENCES



LOCATION HISTORY

THE HISTORICAL ROUTE, ALSO KNOWN AS LOCATION HISTORY, WILL DISPLAY THE HISTORICAL ROUTE OF ANY DAY/TIME WITHIN THE PAST 30 DAY PERIOD AND BEYOND. TO HELP YOU SEE THE PRESENT AND PAST PLACES VISITED.


SELECT A DATE & TIME TO SEE THE TRACKING HISTORY.



CLICK ON ANY OF THE PINPOINTS TO VIEW THE TIMESTAMP OF THE TRACKED EVENT.

SET CONTACT INFO

FROM YOUR MOBILE APP HOME SCREEN, TAP ON DEVICES
SELECT YOUR DEVICE, CLICK ON "SETTINGS" THEN "SMS
ALERTS PHONE#" & "ALERTS E-MAIL"



← Settings

Kim's Backpack

Time Zone:
Eastern

SOS Alerts:
[Email, Notification, SMS]

Battery Alerts:
[Email, Notification, SMS]

Speed Alerts:
0

Speed Limit:
75

Geo-Fence Alerts:
[Email, Notification, SMS]

SOS Phone#:
[Empty field]
[Empty field]
[Empty field]

SMS Alerts Phone#
[Empty field]

Alerts E-Mail:
[Empty field]

SMS ALERTS PHONE:

THE PERSON'S PHONE NUMBER WHO
WILL BE RECEIVING ALERTS FORM THE
DEVICE.

ALERTS E-MAIL:

THE PERSON'S EMAIL ADDRESS WHO
WILL BE RECEIVING ALERTS FORM THE
DEVICE.

UPDATE

MAKE SURE TO SCROLL DOWN AND SAVE THE CHANGES BY CLICKING
ON THE "UPDATE" BUTTON

ENABLING ALERTS

FROM YOUR MOBILE APP HOME SCREEN, TAP ON DEVICES
SELECT YOUR DEVICE, CLICK ON "SETTINGS". YOU WILL
SEE THE OPTIONS TO CHOOSE YOUR ALERTS OPTIONS.

ENABLE THE THESE ALERTS TO SET
THE DEVICE TO SEND
SMS/EMAIL/IN-APP NOTIFICATION
ALERTS TO THE PHONE# & EMAIL
YOU'VE SET (MONITORING)
PERSONNEL AND RECEIVE IN-APP
NOTIFICATIONS

SPEED ALERTS:

CHOOSE HOW YOU WISH TO
RECEIVE YOUR ALERTS (EMAIL, SMS
OR IN-APP NOTIFICATION)

GEO-FENCE ALERTS:

CHOOSE HOW YOU WISH TO
RECEIVE YOUR ALERTS (EMAIL, SMS
OR IN-APP NOTIFICATION)
EVERYTME THE DEVICE ENTERS OR
LEAVES THE GEO FENCE AREA

← Settings

Kim's Backpack

Time Zone:
Eastern

SOS Alerts:
[Email, Notification, SMS]

Battery Alerts:
[Email, Notification, SMS]

Speed Alerts:
[On]

Speed Limit:
75

Geo-Fence Alerts:
[Email, Notification, SMS]

SOS Phone#:
[Empty]

SMS Alerts Phone#:
[Empty]

Alerts E-Mail:
[Empty]

Home, QR, Bell, My Devices icons at the bottom.

UPDATE

MAKE SURE TO SCROLL DOWN AND SAVE THE CHANGES BY CLICKING
ON THE "UPDATE" BUTTON



SET SOS NUMBER

FROM YOUR MOBILE APP HOME SCREEN, TAP ON DEVICES
SELECT YOUR DEVICE, CLICK ON "SETTINGS" THEN "**SOS**
PHONE #"

SET SOS PHONE NUMBER:

LIST OF THE PHONE NUMBER(S) TO
RECEIVE NOTIFICATION SMS AND
CALLS WHEN THE SOS BUTTON IS
TRIGGERED.
YOU CAN SET UP-TO 3 PHONE
NUMBERS.

PLEASE REMEMBER TO PROGRAM
EMERGENCY CONTACT NUMBERS. IT IS
NOT MANDATORY FOR ALL THREE
AUTHORIZED NUMBERS TO BE SET,
HOWEVER A MINIMUM OF ONE MUST
ALWAYS BE SET.

Settings

Kim's Backpack

Time Zone:
Eastern

SOS Alerts:
[Email, Notification, SMS]

Battery Alerts:
[Email, Notification, SMS]

Speed Alerts:
[]

Speed Limit:
75

Geo-Fence Alerts:
[Email, Notification, SMS]

SOS Phone#:
[]
[]
[]

SMS Alerts Phone#
[]

Alerts E-Mail:
[]

Home QR Notifications My Devices

DO NOT LIST 911 AS A PHONE NUMBER IN THE SOS PHONE# LIST

UPDATE

MAKE SURE TO SCROLL DOWN AND SAVE THE CHANGES BY CLICKING
ON THE "**UPDATE**" BUTTON

ANSWER MODE

FROM YOUR MOBILE APP HOME SCREEN, TAP ON DEVICES
SELECT YOUR DEVICE, CLICK ON "**SETTINGS**". TO CHOOSE
HOW YOU WISH THE DEVICE TO ANSWER AN INCOMING
PHONE CALL.

- **PRESS TO ANSWER:** ALLOW YOUR LOVED ONE TO ANSWER A CALL AT THE COMFORT OF THEIR DEVICE WITH ONE TOUCH OF THE ANSWER CALL BUTTON FROM THEIR SOS TRACKER DEVICE.
- **HANDS-FREE AUTO-ANSWER:** AUTO PICK-UP SPEAKERPHONE TO SPEAK TO YOUR LOVED ONE ANYTIME AND INSTANTLY KNOW WHEN YOUR LOVED ONE NEEDS YOU.

← Settings

[Email]

SOS Phone#:

SMS Alerts Phone#

Alerts E-Mail:

Answering Mode: 2

☒ Press Button to Answer ☐ Auto Answer

Phone Book: 3

Phone Book #1 Phone Book #6

Phone Book #2 Phone Book #7

Phone Book #3 Phone Book #8

Phone Book #4 Phone Book #9

Phone Book #5 Phone Book #10

UPDATE

Home Profile Notifications My Devices

UPDATE

MAKE SURE TO SCROLL DOWN AND SAVE THE CHANGES BY CLICKING ON THE "**UPDATE**" BUTTON

PHONE BOOK

FROM YOUR MOBILE APP HOME SCREEN, TAP ON DEVICES
SELECT YOUR DEVICE, CLICK ON "**SETTINGS**" THEN "**PHONE BOOK**"

LIMIT YOUR LOVED ONE'S CONTACTS TO ONLY KNOWN
FAMILY OR FRIENDS, AND THE MAIN PERSON CARING FOR
THE SENIOR **MUST BE SET AS THE PRIMARY CONTACT**
PHONE NUMBER.

SAVE THE PHONE NUMBERS OF THE
FAMILY/FRIENDS.

ONLY NUMBERS IN THE PHONE BOOK
CAN GET THROUGH THE CALLS TO SOS
TRACKER, NUMBERS NOT LISTED HERE
WILL NOT BE ABLE TO CALL THE
NUMBER ASSIGNED TO THE DEVICE.

← Settings

[Email]

SOS Phone#:

SMS Alerts Phone#

Alerts E-Mail:

Answering Mode: ☒ Press Button to Answer ☐ Auto Answer

Phone Book:

| | |
|---------------|----------------|
| Phone Book #1 | Phone Book #6 |
| Phone Book #2 | Phone Book #7 |
| Phone Book #3 | Phone Book #8 |
| Phone Book #4 | Phone Book #9 |
| Phone Book #5 | Phone Book #10 |

UPDATE

MAKE SURE TO SCROLL DOWN AND SAVE THE CHANGES BY CLICKING
ON THE "**UPDATE**" BUTTON

SecuLife®



QUESTIONS?



CALL US
877-606-8080



CONTACT US
WWW.SUPPORT.SECULIFE.US



WATCH VIDEOS
WWW.SECULIFE.US

SAFETY INFORMATION

TO PREVENT INJURY TO YOURSELF AND OTHERS, OR TO AVOID DAMAGE TO THE DEVICE, FIRST READ ALL SAFETY INFORMATION BEFORE USE.

WARNING

- USE MANUFACTURER-APPROVED ACCESSORIES AND SUPPLIES.
- CAUTION – ELECTRICAL OPERATED PRODUCT
- THIS PRODUCT IS NOT A TOY. KEEP OUT OF REACH OF CHILDREN AND PETS UNLESS PROPERLY SUPERVISED. THE PRODUCT CONTAINS SMALL PARTS THAT CAN BE A CHOKING HAZARD.
- DO NOT DROP OR CAUSE AN IMPACT TO THE DEVICE.
- PREVENT THE CHARGING JACK AND CORD FROM COMING INTO CONTACT WITH CONDUCTIVE MATERIALS SUCH AS LIQUIDS, DUST, METALS, PENCIL LEAD, OR AEROSOLS.
- DO NOT STORE YOUR DEVICE IN EXTREMELY HOT OR IN EXTREMELY COLD AREA. RECOMMENDED TO USE YOUR DEVICE FROM 41F TO 95F
- DO NOT STORE YOUR DEVICE NEAR OR ON TOP OF HEATERS, MICROWAVES, HOT COOKING EQUIPMENT, OR HIGH-PRESSURE CONTAINERS.
- DO NOT USE YOUR DEVICE WHILE CHARGING OR TOUCH WITH WET HANDS.
- THE DEVICE AND USB CABLE SHOULD BE PERIODICALLY EXAMINED FOR BREAKS, CRACKS, OR FRAYING, WHICH COULD RISK FIRE, ELECTRICAL SHOCK, OR PERSONAL INJURY. IF

DAMAGED, THE USB CABLE SHOULD BE REPLACED OR REPAIRED BEFORE USE.

- KEEP OUT OF REACH OF CHILDREN AND PETS; SMALL PARTS ARE A CHOKING HAZARD.

CAUTION

- DO NOT DISASSEMBLE, MODIFY, OR REPAIR THE UNIT.
- ANY CHANGES OR MODIFICATIONS TO YOUR DEVICE CAN VOID YOUR MANUFACTURER'S WARRANTY. IF YOUR DEVICE NEEDS SERVICING, CONTACT CUSTOMER SUPPORT.
- DO NOT DISASSEMBLE OR PUNCTURE THE BATTERY, AS THIS CAN CAUSE EXPLOSION OR FIRE.
- DO NOT PAINT OR PUT STICKERS ON YOUR DEVICE. PAINT AND STICKERS CAN CLOG MOVING PARTS AND PREVENT PROPER OPERATION.
- IF YOU ARE ALLERGIC TO PARTS OF THE DEVICE, YOU MAY EXPERIENCE ITCHING, ECZEMA, OR SWELLING OF THE SKIN. WHEN THIS HAPPENS, STOP USING THE DEVICE AND CONSULT YOUR PHYSICIAN.
- ALLOWING UNQUALIFIED PERSONNEL TO SERVICE YOUR DEVICE MAY RESULT IN DAMAGE AND WILL VOID YOUR MANUFACTURER'S WARRANTY.



FOR WARNINGS AND DISCLAIMERS, PLEASE VISIT OUR WEBSITE