



4G GPS SOS WRISTBAND



MODEL# SOS100

USER GUIDE

Visit: www.SecuLife.us

TABLE OF CONTENTS

	CHAPTER 1	3
	QUICK SETUP GUIDE	4
READ ME	GETTING STARTED	5
	CHAPTER 2	10
READ ME	MEET YOUR DEVICE	11
	CHARGING	12
	SOS BUTTON	13
	ANSWER A CALL BUTTON	14
	SPEED DIAL BUTTONS	15
	CHAPTER 3:	16
	MAP PAGE	17
	NOTIFICATIONS	18
	MY DEVICES	19
	DEVICE DETAILS	20
	CREATE A GEO FENCE	21
	CREATE A WIFI FENCE	22
	LOCATION HISTORY	23
READ ME	MAIN CONTACT NUMBER	24
	SMS ALERT SWITCH	25
	SET SOS NUMBER	26
	REMOTE CALL/ EAVES DROP	27
	ANSWER MODE	28
	PHONEBOOK	29
	QUESTIONS	30
	SAFETY INFORMATION/WARNING/CAUTION	31

CHAPTER 1

AN OVERVIEW ON THE QUICK INITIAL SETUP GUIDE

KEEP YOUR LOVED ONES SECURE AND
INDEPENDENT BOTH AT HOME AND ON THE GO.



QUICK SETUP GUIDE

1

ACTIVATE YOUR SERVICE PLAN ONLINE
RECEIVE A NEW PHONE NUMBER FOR
YOUR SOS WRISTBAND

2

SWITCHING DEVICE ON AND OFF
WITH A SIMPLE PRESS OF A BUTTON

3

DOWNLOAD THE MOBILE APP
TO REMOTELY MONITOR YOUR LOVED
ONE. ANYTIME. ANYWHERE!

4

LOGIN TO THE MOBILE APP
USE THE USERNAME AND PASSWORD YOU
ENTERED DURING ACTIVATION, THEN
LOGIN TO OUR APP!

5

UPDATE MOBILE APP SETTINGS
SET THE CORRECT INFO OF THE DEVICE
WEARER AND THE APP USER

1

ACTIVATE YOUR SERVICE PLAN ONLINE

YOUR SECULIFE® SOS WRISTBAND COMES WITH A PREINSTALLED SIM CARD; THE SIM CARD NUMBER IS LOCATED ON THE BOX. ACTIVATE THE SERVICE PLAN ON YOUR SIM ONLINE AND RECEIVE A NEW PHONE NUMBER ASSOCIATED WITH THE SOS WRISTBAND.



VISIT: WWW.ACTIVATE.SECULIFE.US

WE WILL REGISTER YOUR EMAIL ADDRESS AND LINK THE DEVICE TO OUR SECULIFE® MOBILE APP WHEN ACTIVATING YOUR DEVICE SIM CARD, SO YOU DON'T HAVE TO MANUALLY REGISTER TO THE APP. YOU'LL RECEIVE AN EMAIL CONFIRMATION WITH THE NEW NUMBER FOR YOUR RECORDS AND TO BE USED TO UPDATE YOUR MOBILE APP DEVICE INFO ON THE FOLLOWING STEPS.

2

TURN ON THE SOS WRISTBAND

PRESS AND HOLD THE SOS BUTTON ON
THE WRISTBAND FOR 10 SECONDS



IF THE SOS WRISTBAND DOESN'T TURN ON, IT LIKELY NEEDS
TO BE CHARGED. CHARGE THE SOS WRISTBAND FOR
SEVERAL HOURS AND THEN TRY AGAIN.

3

DOWNLOAD THE MOBILE APP

TO DOWNLOAD, SCAN THE QR CODE BELOW FROM YOUR
CELLPHONE:



SECU LIFE



Scan QR Code on
iOS Device



Scan QR Code on
Android Device



www.Seculife.us/ios



www.Seculife.us/android

OUR MOBILE APP IS ALSO AVAILABLE ON APPLE APP
STORE OR GOOGLE PLAY STORE. SEARCH "SECU LIFE" TO
FIND THE APP.

4

LOGIN TO THE MOBILE APP

A FAMILY MEMBER OR THE CAREGIVER CAN OPEN THE MOBILE APP AND LOGIN TO THEIR ACCOUNT WITH A USERNAME AND PASSWORD THAT WAS CREATED DURING THE SIM CARD ACTIVATION PROCESS ONLINE.

- ENTER YOUR EMAIL ADDRESS AS USERNAME.
- ENTER YOUR PASSWORD.

Sign In

Enter username →

Enter Password →

SIGN IN

REGISTER

Biometric login provides a convenient method for authorizing access to your app. Instead of having to remember your username and password every time you open your app

By continuing, you agree to accept our
Privacy Policy & Terms of Service.




Use Biometrics to Sign-in

5

**UPDATE THE
DEVICE INFO ON
YOUR MOBILE APP**

WHEN YOU FIRST ACTIVATE YOUR SOS WRISTBAND'S SIM CARD ONLINE, THE DEVICE WILL BE ADDED INTO YOUR MOBILE APP ACCOUNT AUTOMATICALLY. YOU CAN ACTIVATE MULTIPLE DEVICES ONLINE, MAKE SURE YOU USE THE SAME EMAIL ADDRESS OF YOUR MOBILE APP IN ORDER ADD THE DEVICE UNDER YOUR MOBILE APP LOGIN ACCOUNT.

1. **TAP ON YOUR DEVICE TO GO TO THE DEVICE DETAILS TO SET/UPDATE ITS SETTINGS.**
2. **SET MAIN CONTACT NUMBER:** THE PERSON'S (ADMIN'S) PHONE NUMBER, CARING FOR THE SENIOR, TO RECEIVE APP ALERTS.
3. **SET SOS NUMBER:** LIST OF PHONE NUMBERS TO RECEIVE NOTIFICATION ALERTS WHEN THE SOS BUTTON IS TRIGGERED.



CHAPTER 2

MEET YOUR SECULIFE® SOS SMART WRISTBAND

**A GAME-CHANGING, PERSONAL SECURITY
MONITORING SYSTEM FOR THOSE WHO MATTER
MOST IN YOUR LIFE!**

MEET YOUR SOS SMART WRISTBAND

FRONT

Built-in speaker for listening during 2-way calls.



BACK

Magnet Charging Port



Use Device IMEI to Add A New Device Manually

THE FOLLOWING TABLES DESCRIBE THE LED LIGHTS



Red LED

WHEN POWERED ON

Network Indicator

Slow Blinking	Signal Searching
Fast Blinking	Signal Received

WHILE CHARGING

Slow Blinking	Device is Charging
Solid Red	Fully Charged



Blue LED

WHEN POWERED ON

GPS Indicator

Slow Blinking	GPS Positioning
Fast Blinking	Position Uploaded

WHILE CHARGING

Slow Blinking	Device is Charging
Solid Red	Fully Charged

CHARGING

USE ONLY THE SECULIFE® AUTHORIZED MAGNETIC CHARGING

FIRST TIME CHARGE

WE RECOMMEND FULLY CHARGING THE SOS WRISTBAND FOR 8-HOURS BEFORE USING IT FOR THE FIRST TIME. IN THE MEANTIME, YOU CAN ACTIVATE THE SIM CARD THAT COMES WITH THE SOS WRISTBAND IF YOU HAVEN'T DONE IT YET.

CHARGE YOUR DEVICE

CONNECT THE MAGNETIC CHARGING CABLE TO THE CHARGING PORT LOCATED ON THE BACK OF THE WRISTBAND AND LET IT CHARGE FOR AT LEAST 4-5 HOURS.



AVOID LEAVING THE MAGNETIC CABLE PORT ON METAL SURFACES TO AVOID A SHORT CIRCUIT THAT MIGHT CAUSE DAMAGE OR FIRE.

SOS BUTTON

SOS WILL IMMEDIATELY CONTACT THE EMERGENCY CONTACT LIST AND SEND AN SMS ALERT AND IN-APP ALERT.

TO ACTIVATE THE SOS ON THE DEVICE, HIT THE SOS BUTTON FOR 5 SECONDS.

UPON TRIGGERING THE SOS BUTTON BY THE DEVICE WEARER, THE MOBILE APP WILL RECEIVE AN IMMEDIATE NOTIFICATION OF THE WEARER'S LOCATION AND ITS SOS STATUS. UPON RECEIVING AN SOS ALERT, YOU CAN IMMEDIATELY SEE HIS/HER LOCATION ON THE MAP, CALL YOUR LOVED ONE TO ENSURE SAFETY.

SOS BUTTON HAS OTHER FUNCTIONS BESIDES SENDING THE SOS ALERTS. FOR EXAMPLE, DURING A PHONE CALL, PRESS ON SOS BUTTON ONCE TO HANG UP THE CALL. SEE BELOW FUNCTIONS

SOS BUTTON FUNCTIONS

Tap Once	<ul style="list-style-type: none">• Announces the time• Hangup ongoing call
Press and Hold for 5 seconds	Sends SOS alert to the emergency contacts
Press and Hold for 10 seconds	Turn On / Off the device

SOS BUTTON



ANSWER A CALL BUTTON



ANSWER A CALL BUTTON

WHEN RECEIVING A PHONE CALL, PRESS ON THE VOICE MESSAGE BUTTON TO ANSWER THE INCOMING CALL; IF THE DEVICE "ANSWER MODE" IS SET TO "PRESS TO ANSWER."

ANSWER A
CALL
BUTTON





SPEED DIAL BUTTONS

THERE ARE TWO EASY-TO-USE SPEED DIAL BUTTONS TO QUICKLY CALL THE PERSONS ON YOUR PHONE BOOK DURING AN EMERGENCY OR WHEN YOU NEED TO CALL AND STAY IN TOUCH.

- SPEED DIAL 1: PRESS TO CALL THE FIRST CONTACT SAVED ON MOBILE APP'S PHONE BOOK
- SPEED DIAL 2: PRESS TO CALL THE SECOND CONTACT SAVED ON THE MOBILE APP'S PHONE BOOK

SPEED DIAL 1

SPEED DIAL 2



CHAPTER 3

MEET OUR MOBILE APP

A NEW, NEXT-LEVEL, AND EASY WAY TO PROTECT
AND CONNECT WITH YOUR LOVED ONE. ANYTIME,
ANYWHERE!


MAP PAGE

MOBILE APP HOME SCREEN WILL DISPLAY THE **MAP** AND THE DEVICE(S) LAST SEEN LOCATION ON THE MAP. MOBILE APP ALSO HAVE OTHER FUNCTIONS AVAILABLE (**ADD FENCES, NOTIFICATIONS, MY DEVICES**) ON THE FUNCTION BAR TO TRACK, LOCATE AND SETUP THE SOS WRISTBAND AT YOUR CONVENIENT.

CLICK TO SEE
DEVICE NAME

YOU CAN CLICK ON THE DEVICE TO SEE THE DEVICE NAME. THE NAME CAN BE CHANGED FROM MY DEVICES PAGE.

YOU CAN SEE ALL OF YOUR DEVICES ON YOUR MAP, IF YOU HAVE MORE THAN A DEVICE ADDED TO YOUR MOBILE APP,






NOTIFICATIONS

SEE ALL THE NOTIFICATION RECEIVED FROM YOUR DEVICE

SEE THE ALERT TYPE AND THE DEVICE NAME WITH THE DATE & TIME OF THE ALERT.

IF YOU HAVE MULTIPLE DEVICES ADDED TO YOUR MOBILE APP, YOU WILL SEE ALL THE NOTIFICATIONS FOR ALL OF YOUR DEVICES FROM THIS NOTIFICATION PAGE. TO SEE THE NOTIFICATIONS OF A SPECIFIC DEVICE ONLY, YOU CAN GO TO: **MY DEVICES >> SELECT A DEVICE >> NOTIFICATIONS BUTTON ON THAT PAGE.**

Notifications	
Fence Notification	11/09/2021 16:03
Device Susan is out of fence DR's Fence	
Fence Notification	11/09/2021 14:17
Device Susan is back to fence DR's Fence	
Fence Notification	11/08/2021 12:22
Battery Low Alert from Susan	
Fence Notification	11/04/2021 18:34
Device Susan is back to fence Home	
Fence Notification	11/04/2021 14:58
SOS Alert from Susan	
Fence Notification	11/04/2021 14:48
SOS Alert from Susan	
Fence Notification	11/03/2021 16:31
Device Susan is out of fence Park Fence	
Fence Notification	11/03/2021 16:03
Device Susan is back to fence Park Fence	
Fence Notification	11/02/2021 14:55
Device Susan is out of fence Home	



Settings

MY DEVICES

FROM YOUR MOBILE APP HOME SCREEN, TAP ON "MY DEVICES" TO SEE LIST OF DEVICES, IF YOU HAVE MULTIPLE DEVICES. CLICK ON THE DEVICE TO GO TO THE "DEVICE DETAILS".

Click on + to Add a new Device

From **My Devices** page you will see

- Device Name (The name can be changed from Device Details)
- Battery level
- Device SIM card and IMEI #
- Last seen date/time.

Click on a device to go to "**Device Details**" to setup and update the device information at anytime.

*Device status Types

- Online: This is when Device status indicates its online and connected to the App.
- Offline: This is when the device is switched off or no network signal is detected.

My Devices



Susan's SOS Wristband 78%
SIM: 8901
IMEI: 8651
Last Seen: 11/02/2021 14:56



David SOS Wristband 81%
SIM: 8901
IMEI: 8651
Last Seen: 11/11/2021 15:51

Click "My Devices" to see your device list



Settings

DEVICE DETAILS

FROM YOUR MOBILE APP HOME SCREEN, TAP ON "MY DEVICES" THEN CLICK ON THE DESIRED DEVICE TO ACCESS AND TO GO TO ITS "DEVICE DETAILS". NOTIFICATIONS | HISTORY | SETTINGS WILL BE EXPLAINED ON THE FOLLOWING PAGES ON THIS CHAPTER

GEO FENCES:


SELECT THE DESIRED GEO-FENCE (SUCH AS HOME, DOCTOR'S OFFICE, PARK... ETC.) TO RECEIVE ALERTS WHEN THE DEVICE ENTERS OR LEAVES THESE AREAS.

WIFI FENCE:

RECEIVE ALERTS WHEN THE DEVICE ENTERS OR LEAVES A WIFI RANGE OF A SELECTED WIFI NETWORK.

TRACKING INTERVAL:

SET UP LOCATION UPLOAD INTERVALS. THIS IS HOW OFTEN DO YOU WISH THE DEVICE TO REPORT THE LOCATION, WE SUGGEST TO SETUP TO 12 HOURS TO ENHANCE BATTERY-SAVING MODE; THIS WILL ENSURE THE DEVICE HAS SUFFICIENT BATTERY POWER FOR ANY POTENTIAL SOS ALERTS.



GEO-FENCE

GEO FENCING, ALSO KNOWN AS "SAFE ZONES," CAN BE SET UP FROM THE MOBILE APP; YOU CAN ADD, EDIT OR REMOVE A GEO-FENCE AREA. ONCE A GEO FENCE IS CREATED YOU CAN SELECT THE FENCE(S), FROM DEVICE DETAILS PAGE, TO RECEIVE ALERTS WHEN ENTERING OR EXITING A GEO-FENCE AREA.

ADD GEO FENCE:

- CLICK ON **NEW FENCE** BUTTON FIRST THEN SET A PERIMETER ON THE MAP
- CLICK ON **SAVE** BUTTON AND ENTER THE FENCE NAME (SUCH AS HOME, DOCTOR'S OFFICE, PARK... ETC.).


RECOMMENDED GPS RADIUS OF 1000 FEET OR HIGHER TO REDUCE FALSE ALERTS.

YOU CAN SETUP MULTIPLE GEO FENCE LOCATIONS AS NEEDED.

DELETE GEO FENCE:

- TO DELETE A GEO FENCE, CLICK ON THE DESIRED FENCE FIRST, THEN CLICK ON **DELETE** BUTTON

CLICK TO ADD OR DELETE FENCES



WIFI FENCE


THIS FEATURE IS AVAILABLE ON OUR SOS WRISTBAND DEVICE. SELECT A WIFI FENCE ON YOUR DEVICE DETAILS AND RECEIVE ALERTS WHEN THE DEVICE LEAVES THE WIFI RAGE.

SELECT THE WIFI FROM THE DROP-DOWN LIST.

PLEASE NOTE: THE WIFI IN THE SOS WRISTBAND DOESN'T SUPPORT A 5G-WIFI CONNECTION.

- ANDROID PHONES SHALL CHOOSE 2.4G WIFI AS THE HOTSPOT OF THE WIFI FENCE.
- IF YOU ARE USING THE MOBILE APP ON YOUR IPHONE, YOUR PHONE WILL CONNECT TO THE WIFI AND WILL SET IT AS THE WIFI FENCE HOTSPOT AUTOMATICALLY.

IF YOUR IPHONE IS CONNECTED TO A 5G-WIFI, PLEASE SWITCH YOUR WIFI CONNECTION ON YOUR IPHONE TO 2.4G FIRST; OTHERWISE, DON'T SET A WIFI FENCE TO AVOID SETTING A NON-FUNCTIONING WIFI FENCE; THIS WILL PREVENT FALSE ALARMS.




LOCATION HISTORY

THE HISTORICAL ROUTE, ALSO KNOWN AS LOCATION HISTORY, WILL DISPLAY THE HISTORICAL ROUTE OF ANY DAY WITHIN THE PAST 30 DAY PERIOD AND BEYOND. TO HELP YOU SEE THE PRESENT AND PAST PLACES VISITED.

SELECT A DATE TO SEE THE TRACKING HISTORY.

CLICK ON ANY OF THE PINPOINTS TO VIEW THE TIMESTAMP OF THE TRACKED EVENT.



ADMIN

MAIN CONTACT
NUMBER

MAIN CONTACT NUMBER

FROM YOUR MOBILE APP HOME SCREEN, TAP ON DEVICES
SELECT YOUR DEVICE, CLICK ON "SETTINGS" THEN "MAIN
CONTACT NUMBER."

MAIN CONTACT NUMBER:

ALSO KNOWN AS THE **ADMIN** NUMBER,
THE PERSON'S PHONE NUMBER
CARING FOR THE SENIOR/LOVED
ONE'S; THIS NUMBER WILL RECEIVE
APP ALERTS.

← Settings

Susan's SOS Wristband

Main Contact Number: [Red Arrow Points Here] [Input Field]

SOS SMS Alert ☒ Low Battery SMS Alert ☒

SOS Phone#: [Input Field]

[Input Field]

SOS E-Mail: [Input Field]

Remote Call / Eaves Drop: ⓘ [Input Field] **CALL**

Answering Mode: ⓘ

☐ Press Button to Answer ☒ Hands Free Auto Answer

Phone Book: ⓘ

[Input Field] [Input Field]

[Input Field] [Input Field]

[Input Field] [Input Field]

Home, SOS, Bell, My Devices icons at the bottom.

UPDATE

MAKE SURE TO SCROLL DOWN AND SAVE THE CHANGES BY CLICKING
ON THE "**UPDATE**" BUTTON

SMS ALERT SWITCH

FROM YOUR MOBILE APP HOME SCREEN, TAP ON DEVICES
SELECT YOUR DEVICE, CLICK ON "**SETTINGS**". YOU WILL
SEE THE T ENABLED/DISABLE SMS ALERT OPTIONS.

MAIN CONTACT NUMBER CAN BE
SET HERE

ENABLE THE SWITCHES TO SET
THE DEVICE TO SEND SMS ALERTS
TO THE MAIN CONTACT
(MONITORING) NUMBER.

Settings

Susan's SOS Wristband

Main Contact Number:

2000000000

SOS SMS Alert ☒ Low Battery SMS Alert ☒

SOS Phone:

6000000000

2000000000

SOS E-Mail:

6000000000

Remote Call / Eaves Drop: 0

CALL

Answering Mode: 0

☐ Press Button to Answer ☒ Hands Free Auto Answer

Phone Book: 0

6000000000

6000000000

6000000000

Home, SOS, Notifications, My Devices

UPDATE

MAKE SURE TO SCROLL DOWN AND SAVE THE CHANGES BY CLICKING
ON THE "**UPDATE**" BUTTON

SET SOS NUMBER

FROM YOUR MOBILE APP HOME SCREEN, TAP ON DEVICES
SELECT YOUR DEVICE, CLICK ON "SETTINGS" THEN "SOS
PHONE #"

SET SOS PHONE NUMBER:

LIST OF THE PHONE NUMBER(S) TO
RECEIVE NOTIFICATION SMS AND
CALLS WHEN THE SOS BUTTON IS
TRIGGERED.
YOU CAN SET UP-TO 3 PHONE
NUMBERS.

SOS E-MAIL:

SET THE EMAIL TO RECEIVE THE SOS
ALERTS WHEN TRIGGERED.

← Settings

Susan's SOS Wristband

Main Contact Number:

SOS SMS Alert ☒ Low Battery SMS Alert ☒

SOS Phone#:

SOS E-Mail:

Remote Call / Eaves Drop: ☐ CALL

Answering Mode: ☐ Press Button to Answer ☒ Hands Free Auto Answer

Phone Book:

My Devices

UPDATE

MAKE SURE TO SCROLL DOWN AND SAVE THE CHANGES BY CLICKING
ON THE "UPDATE" BUTTON

REMOTE CALL/ EAVES DROP

STAY CONNECTED WITH YOUR LOVED ONE. YOU CAN CONVENIENTLY CALL YOUR LOVED ONE'S DEVICE PHONE NUMBER USING YOUR MOBILE APP TO CHECK ON THEIR SURROUNDINGS.

SIMPLY CLICK ON **CALL** BUTTON FROM THE DEVICE SETTING PAGE THIS FEATURE WILL ALLOW YOU TO EAVESDROP ON YOUR LOVED ONE TO CHECK IF THEY ARE SAFE.

THE NUMBER YOU ENTER WILL RECEIVE A CALL FROM THE DEVICE TO ALLOW YOU TO LISTEN-IN ONLY. THE END USER WILL NOT BE ABLE TO HEAR YOU.

Settings

Susan's SOS Wristband

Main Contact Number:

SOS SMS Alert ☒ Low Battery SMS Alert ☒

SOS Phone#:

SOS E-Mail:

Remote Call / Eaves Drop: ☒ **CALL**

Answering Mode: ☒

☐ Press Button to Answer ☒ Hands Free Auto Answer

Phone Book:

My Devices

ANSWER MODE

FROM YOUR MOBILE APP HOME SCREEN, TAP ON DEVICES
SELECT YOUR DEVICE, CLICK ON "**SETTINGS**". TO CHOOSE
HOW YOU WISH THE DEVICE TO ANSWER AN INCOMING
PHONE CALL.

- **PRESS TO ANSWER:** ALLOW YOUR LOVED ONE TO ANSWER A CALL AT THE COMFORT OF THEIR WRISTBAND WITH ONE TOUCH OF THE ANSWER CALL BUTTON FROM THEIR SOS WRISTBAND.
- **HANDS-FREE AUTO-ANSWER:** AUTO PICK-UP SPEAKERPHONE TO SPEAK TO YOUR LOVED ONE ANYTIME AND INSTANTLY KNOW WHEN YOUR LOVED ONE NEEDS YOU.

← Settings

Susan's SOS Wristband

Main Contact Number:
2

SOS SMS Alert ☒ Low Battery SMS Alert ☒

SOS Phone#:
6
2

SOS E-Mail:
-

Remote Call / Eaves Drop: ☐ CALL

Answering Mode: ☒ Press Button to Answer ☐ Hands Free Auto Answer

Phone Book:

Home SOS Notifications My Devices

UPDATE

MAKE SURE TO SCROLL DOWN AND SAVE THE CHANGES BY CLICKING ON THE "**UPDATE**" BUTTON

PHONE BOOK

FROM YOUR MOBILE APP HOME SCREEN, TAP ON DEVICES
SELECT YOUR DEVICE, CLICK ON "SETTINGS" THEN "**PHONE BOOK**"

LIMIT YOUR LOVED ONE'S CONTACTS TO ONLY KNOWN
FAMILY OR FRIENDS, AND THE MAIN PERSON CARING FOR
THE SENIOR **MUST BE SET AS THE PRIMARY CONTACT
PHONE NUMBER.**

SAVE THE PHONE NUMBERS OF THE
FAMILY/FRIENDS.

THE FIRST TWO NUMBERS ARE STORED
IN THE SOS WRISTBAND SPEED DIAL
KEY 1 & 2.

WHITELIST: ONLY NUMBERS IN THE
PHONE BOOK CAN GET THROUGH THE
CALLS TO SOS WRISTBAND, NUMBERS
NOT LISTED HERE WILL NOT BE ABLE
TO CALL THE NUMBER ASSIGNED TO
THE DEVICE.

← Settings ⓘ

Susan's SOS Wristband

Main Contact Number:

SOS SMS Alert ☒ Low Battery SMS Alert ☒

SOS Phone:

SOS E-Mail:

Remote Call / Eaves Drop: ⓘ

Answering Mode: ⓘ
☐ Press Button to Answer ☒ Hands Free Auto Answer

Phone Book: ⓘ

UPDATE

MAKE SURE TO SCROLL DOWN AND SAVE THE CHANGES BY CLICKING
ON THE "**UPDATE**" BUTTON

SecuLife®



QUESTIONS?



CALL US
877-606-8080



CONTACT US
WWW.SUPPORT.SECULIFE.US



WATCH VIDEOS
WWW.SECULIFE.US

SAFETY INFORMATION

TO PREVENT INJURY TO YOURSELF AND OTHERS, OR TO AVOID DAMAGE TO THE DEVICE, FIRST READ ALL SAFETY INFORMATION BEFORE USE.

WARNING

- USE MANUFACTURER-APPROVED ACCESSORIES AND SUPPLIES.
- CAUTION – ELECTRICAL OPERATED PRODUCT
- THIS PRODUCT IS NOT A TOY. KEEP OUT OF REACH OF CHILDREN AND PETS UNLESS PROPERLY SUPERVISED. THE PRODUCT CONTAINS SMALL PARTS THAT CAN BE A CHOKING HAZARD.
- DO NOT DROP OR CAUSE AN IMPACT TO THE DEVICE.
- PREVENT THE CHARGING JACK AND CORD FROM COMING INTO CONTACT WITH CONDUCTIVE MATERIALS SUCH AS LIQUIDS, DUST, METALS, PENCIL LEAD, OR AEROSOLS.
- DO NOT STORE YOUR DEVICE IN EXTREMELY HOT OR IN EXTREMELY COLD AREA. RECOMMENDED TO USE YOUR DEVICE FROM 41F TO 95F
- DO NOT STORE YOUR DEVICE NEAR OR ON TOP OF HEATERS, MICROWAVES, HOT COOKING EQUIPMENT, OR HIGH-PRESSURE CONTAINERS.
- DO NOT USE YOUR DEVICE WHILE CHARGING OR TOUCH WITH WET HANDS.
- THE DEVICE AND USB CABLE SHOULD BE PERIODICALLY EXAMINED FOR BREAKS, CRACKS, OR FRAYING, WHICH COULD RISK FIRE, ELECTRICAL SHOCK, OR PERSONAL INJURY. IF

DAMAGED, THE USB CABLE SHOULD BE REPLACED OR REPAIRED BEFORE USE.

- KEEP OUT OF REACH OF CHILDREN AND PETS; SMALL PARTS ARE A CHOKING HAZARD.

CAUTION

- DO NOT DISASSEMBLE, MODIFY, OR REPAIR THE UNIT.
- ANY CHANGES OR MODIFICATIONS TO YOUR DEVICE CAN VOID YOUR MANUFACTURER'S WARRANTY. IF YOUR DEVICE NEEDS SERVICING, CONTACT CUSTOMER SUPPORT.
- DO NOT DISASSEMBLE OR PUNCTURE THE BATTERY, AS THIS CAN CAUSE EXPLOSION OR FIRE.
- DO NOT PAINT OR PUT STICKERS ON YOUR DEVICE. PAINT AND STICKERS CAN CLOG MOVING PARTS AND PREVENT PROPER OPERATION.
- IF YOU ARE ALLERGIC TO PARTS OF THE DEVICE, YOU MAY EXPERIENCE ITCHING, ECZEMA, OR SWELLING OF THE SKIN. WHEN THIS HAPPENS, STOP USING THE DEVICE AND CONSULT YOUR PHYSICIAN.
- ALLOWING UNQUALIFIED PERSONNEL TO SERVICE YOUR DEVICE MAY RESULT IN DAMAGE AND WILL VOID YOUR MANUFACTURER'S WARRANTY.



FOR WARNINGS AND DISCLAIMERS, PLEASE VISIT OUR WEBSITE